



Eaton® Transmission

# Service Manual

---

FSO-2105 / 2505  
February 2012  
Rev. 0

# Table of Contents

---

## Introduction

|                                                |    |
|------------------------------------------------|----|
| Purpose and Scope of the Manual .....          | 1  |
| How to Use this Manual .....                   | 1  |
| Warnings and Precautions .....                 | 2  |
| Identification .....                           | 3  |
| Model designation .....                        | 3  |
| Gear Ratio .....                               | 4  |
| Exploded Views .....                           | 5  |
| Direct Control Assembly                        |    |
| FSO-2105 / FSO-2505 (4x2 and 4x4) Models ..... | 5  |
| Shift Yokes and Bars                           |    |
| FSO-2105 / FSO-2505 (4x2 and 4x4) Models ..... | 6  |
| Transmission Case Assembly                     |    |
| FSO-2105 / FSO-2505 (4x2) Models .....         | 7  |
| FSO-2105 / FSO-2505 (4x4) Models .....         | 8  |
| Input Shaft / Mainshaft Assembly               |    |
| FSO-2105 / FSO-2505 (4x2 and 4x4) Models ..... | 9  |
| Countershaft Assembly                          |    |
| FSO-2105 / FSO-2505 (4x2 and 4x4) Models ..... | 10 |
| Lubrication Information .....                  | 11 |
| Operation .....                                | 13 |
| Gear shift lever pattern .....                 | 13 |
| Power Flow .....                               | 14 |
| Adhesive and Sealant Application .....         | 16 |
| Torque Recommendation .....                    | 17 |
| Precautions .....                              | 19 |
| Troubleshooting .....                          | 21 |
| Tool Information .....                         | 26 |
| Universal Tools .....                          | 26 |
| Essential Special Tools .....                  | 27 |
| Complementary Tools .....                      | 29 |
| Installation Reference .....                   | 31 |
| FSO-2105 Model                                 |    |
| Application Flex 2.4L SOHC 4x2 .....           | 31 |
| Application Flex 2.4L SOHC 4x4 .....           | 33 |
| FSO-2505 Model                                 |    |
| Application Diesel 4x2 2.5 2.8 .....           | 35 |
| Application Diesel 4x4 2.5 2.8 .....           | 37 |
| Application HFV6 4x2 .....                     | 39 |
| Application HFV6 4x4 .....                     | 41 |

# Table of Contents

---

## Gear Shift Lever Housing

|                                           |    |
|-------------------------------------------|----|
| Gear Shift Lever Housing Disassembly..... | 43 |
| Gear Shift Lever Housing Assembly.....    | 44 |

## Rear Section

|                                |    |
|--------------------------------|----|
| Rear Section Disassembly ..... | 47 |
| Oil Seal Replacement.....      | 52 |
| Rear Section Assembly .....    | 52 |

## Front Section

|                                          |    |
|------------------------------------------|----|
| Front Section Disassembly.....           | 59 |
| Mainshaft                                |    |
| Disassembly.....                         | 61 |
| Assembly.....                            | 61 |
| Countershaft                             |    |
| Disassembly.....                         | 65 |
| Assembly.....                            | 65 |
| Input Shaft                              |    |
| Disassembly.....                         | 66 |
| Assembly.....                            | 66 |
| Shift Yoke Bars                          |    |
| Disassembly.....                         | 67 |
| Assembly.....                            | 67 |
| Expansion Plugs                          |    |
| Removal .....                            | 69 |
| Installation .....                       | 70 |
| Permaglide Bushing                       |    |
| Removal .....                            | 70 |
| Installation .....                       | 71 |
| Reverse Shifting Interlocking System     |    |
| Description .....                        | 71 |
| Disassembly.....                         | 72 |
| Assembly.....                            | 72 |
| Double Gear Shifting Interlocking System |    |
| Description .....                        | 73 |
| Disassembly.....                         | 74 |
| Assembly.....                            | 74 |

# Table of Contents

---

|                                                               |    |
|---------------------------------------------------------------|----|
| Input Shaft Bearing Cup                                       |    |
| Removal .....                                                 | 75 |
| Installation .....                                            | 75 |
| Input Shaft Oil Baffle and Oil Seal                           |    |
| Removal .....                                                 | 76 |
| Installation .....                                            | 76 |
| Countershaft Front Bearing Cup                                |    |
| Removal .....                                                 | 77 |
| Installation .....                                            | 77 |
| Mainshaft and Countershaft Rear Bearing Cups                  |    |
| Removal .....                                                 | 78 |
| Installation .....                                            | 78 |
| Synchronizer Assemblies                                       |    |
| Description .....                                             | 79 |
| 1st/2nd Speed Synchronizer .....                              | 79 |
| 3rd/4th Speed Synchronizer .....                              | 81 |
| 5th/Reverse Speed Synchronizer .....                          | 83 |
| Front Section Assembly .....                                  | 84 |
| End Play Adjustment                                           |    |
| Mainshaft End Play Measurement .....                          | 88 |
| Countershaft End Play Measurement .....                       | 89 |
| Determining Shim Pack Thickness for End Play Adjustment ..... | 89 |



## Purpose and Scope of the Manual

This manual is designed to provide detailed information necessary to service and repair Eaton® transmissions FSO-2105 and FSO-2505.

## How to Use this Manual

Disassembly and assembly instructions in this manual make use of a typical FSO-2105 or FSO-2505 transmission. Provided illustrations and pictures show parts that may differ from one transmission model to another, according to its application and serial number.

In addition, it is also assumed in the manual that the transmission has been removed from the vehicle and the lubricant has been drained.

The manual has been divided into two main groups as follows:

1. Information and technical references, placed all together into one section.
2. Disassembly and assembly instructions, by its turn, divided into sections gathering specific component assemblies.

For the complete disassembly and assembly of the transmission, follow the manual in its natural sequence. However, if only a component should be serviced, locate in the index the section to which the component belongs and the page number referring to it.

For more detailed information on product improvement, repair procedures and other subjects related to service, please contact:

**Eaton Ltda. – Transmission Division**  
**After Sales & Service Support**  
**Rua Clark, 2061 – PO Box 304**  
**13270 - Valinhos - São Paulo - Brazil**  
**Phone: 0800-170551**  
**Fax: +55 19 3881-9858**

**WARNING!** Eaton reserves the right to make modifications in its products and to change specifications included in this manual at any time without previous notice.

## Warnings and Precautions



**Before starting a vehicle always be seated in the driver's seat, place the transmission in neutral, set the parking brakes and disengage the clutch.**

**Before working on a vehicle place the transmission in neutral, set the parking brakes and block the wheels.**

Before towing the vehicle place the transmission in neutral, and lift the rear wheels off the ground, or remove the axle shafts, or disconnect the driveline to avoid damage to the transmission during towing.

The description and specifications contained in this service publication are current at the time of printing.

Eaton Corporation reserves the right to discontinue or modify its models and/or procedures and to change specifications at any time without notice.

Any reference to brand name in this publication is made as an example of the types of tools and materials recommended for use and should not be considered an endorsement. Equivalents may be used.



This symbol is used throughout this manual to call attention to procedures where carelessness or failure to follow specific instructions may result in personal injury and/or component damage.

Departure from the instructions, choice of tools, materials and recommended parts mentioned in this publication may jeopardize the personal safety of the service technician or vehicle operator.

**WARNING:** Failure to follow indicated procedures creates a high risk of personal injury to the servicing technician.

**Caution:** Failure to follow indicated procedures may cause component damage or malfunction.


**Note:** Additional service information not covered in the service procedures.

**Tip:** Helpful removal and installation procedures to aid in the service of this unit.

**Always use genuine Eaton replacement parts.**


## Model designation

All Eaton transmissions are identified by the model designation and serial number. This information is stamped on the identification plate fixed to the transmission case.



**WARNING!** Do not remove or destroy the transmission identification plate.

**Note:** When ordering replacement parts or calling for service support, please inform identification plate numbers.



## Gear Ratio

|              |       | FSO 2105 |       | FSO 2505 |       |     |       |
|--------------|-------|----------|-------|----------|-------|-----|-------|
|              |       | A        |       | A        |       | B   |       |
| Torque       | N.m   | 270      |       | 440      |       | 440 |       |
|              | Lb.ft | 200      |       | 325      |       | 325 |       |
|              |       | ND       | Ratio | ND       | Ratio | ND  | Ratio |
| Input shaft  |       | 26       |       | 26       |       | 26  |       |
| Countershaft |       | 37       |       | 37       |       | 37  |       |
| 1st          | (CE)  | 14       | 4.47  | 15       | 4.08  | 15  | 4.08  |
|              | (EP)  | 44       |       | 43       |       | 43  |       |
| 2nd          | (CE)  | 22       | 2.46  | 23       | 2.29  | 23  | 2.29  |
|              | (EP)  | 38       |       | 37       |       | 37  |       |
| 3rd          | (CE)  | 29       | 1.47  | 29       | 1.47  | 29  | 1.47  |
|              | (EP)  | 30       |       | 30       |       | 30  |       |
| 4th          | (CE)  | -        | 1.00  | -        | 1.00  | -   | 1.00  |
|              | (EP)  | -        |       | -        |       | -   |       |
| 5th          | (CE)  | 45       | 0.82  | 53       | 0.72  | 51  | 0.81  |
|              | (EP)  | 26       |       | 27       |       | 29  |       |
| Reverse      | (CE)  | 12       | 3.79  | 12       | 3.79  | 12  | 3.79  |
|              | (RV)  | 29       |       | 29       |       | 29  |       |
|              | (EP)  | 32       |       | 32       |       | 32  |       |

**ND** = Number of teeth in gear

**CE** = Countershaft

**EP** = Mainshaft

**RV** = Reverse idle gear

**Ratio:** Gear ratio. It is calculated by dividing the number of teeth in driven gear by the number of teeth in drive gear, and then multiplying by the input gear pair ratio.

Example:

FSO-2105


Input pair: Input shaft = 26 teeth; = 37 teeth =>  $37/26 = 1.423 \sim$

First gear: Countershaft = 14 teeth; Mainshaft = 44 teeth =>  $44/14 = 3.143 \sim$

$1.423 \times 3.143 = 4.472 \sim$

## Direct Control Assembly


### FSO-2105 / FSO-2505 (4x2 and 4x4) Models



- |                                      |                                   |                             |
|--------------------------------------|-----------------------------------|-----------------------------|
| 1. Gear shift lever housing          | 7. Thrust washer                  | 13. Flat washer             |
| 2. Threaded pin                      | 8. Boot                           | 14. Support spacer          |
| 3. Locating pin                      | 9. Gear shift lever               | 15. Shock-absorbing bushing |
| 4. Spring                            | 10. Pivot pin                     | 16. Washer                  |
| 5. Threaded plug                     | 11. Gear shift lever bushing      | 17. Screw M8 x 35           |
| 6. Gear shift lever pivoting support | 12. Shock-absorbing rubber gasket |                             |

## Shift Yokes and Bars

### FSO-2105 / FSO-2505 (4x2 and 4x4) Models




FSO-2105/explo4

- |                                       |                                   |                                   |
|---------------------------------------|-----------------------------------|-----------------------------------|
| 30. 3rd/4th speed shift yoke assembly | 41. Yoke pads                     | 52. Roll pin                      |
| 31. Yoke pads                         | 42. Roll pin                      | 53. 5th/reverse speed shift block |
| 32. Roll pin                          | 43. Shift selector block assembly | 54. Roll pin                      |
| 33. 3rd/4th speed shift block         | 44. Bushing                       | 55. 5th/reverse speed yoke bar    |
| 34. Roll pin                          | 45. Pin                           | 56. 5th/reverse speed shift block |
| 35. 3rd/4th speed yoke bar            | 46. Washer                        | 57. Roll pin                      |
| 36. Ball                              | 47. Spring                        | 58. 5th/reverse speed shift yoke  |
| 37. Ball                              | 48. Spring support                | 59. Swivel holder                 |
| 38. Spacer pin                        | 49. Snap ring                     | 60. Yoke pads                     |
| 39. 1st/2nd speed yoke bar            | 50. Shift selector bar (main bar) |                                   |
| 40. 1st/2nd speed shift yoke assembly | 51. Shift lug (4x4)               |                                   |
|                                       | 51a. Shift lug (4x2)              |                                   |

## Transmission Case Assembly


### FSO-2105 / FSO-2505 (4x2) Models



- |                           |                          |                              |
|---------------------------|--------------------------|------------------------------|
| 70. Front housing         | 84. Threaded pin         | 98. Actuator                 |
| 71. Oil seal              | 85. Screw                | 99. Actuator's spring        |
| 72. Screw                 | 86. Dowel pin            | 100. Threaded plug           |
| 73. Plug                  | 87. Screw                | 101. Magnetic speed sensor   |
| 74. Bearing               | 88. Harness bracket      | 102. Screw                   |
| 75. Dowel pin             | 89. Reverse light switch | 103. Oil pick-up             |
| 76. Oil baffle            | 90. Ball                 | 104. Reverse idle gear shaft |
| 77. Plug                  | 91. Lock spring          | 105. Needle bearing          |
| 78. Reverse lock spring   | 92. Threaded plug        | 106. Reverse idle gear       |
| 79. Cup plug              | 93. Drain plug           | 107. Bearing                 |
| 80. Roll pin              | 94. Bracket              | 108. Shifting guide          |
| 81. Reverse lock assembly | 95. Rear housing         | 109. Screw                   |
| 82. Intermediate housing  | 96. Oil seal             | 110. Bracket                 |
| 83. Filling plug          | 97. Actuator's bushing   | 111. Bracket                 |

## Transmission Case Assembly


### FSO-2105 / FSO-2505 (4x4) Models



- |                           |                          |                              |
|---------------------------|--------------------------|------------------------------|
| 70. Front housing         | 83. Filling plug         | 96. Actuator's bushing       |
| 71. Oil seal              | 84. Threaded pin         | 97. Actuator                 |
| 72. Screw                 | 85. Screw                | 98. Actuator's spring        |
| 73. Plug                  | 86. Dowel pin            | 99. Threaded plug            |
| 74. Bearing               | 87. Screw                | 100. Oil pick-up             |
| 75. Dowel pin             | 88. Harness bracket      | 101. Reverse idle gear shaft |
| 76. Oil baffle            | 89. Reverse light switch | 102. Needle bearing          |
| 77. Plug                  | 90. Ball                 | 103. Reverse idle gear       |
| 78. Reverse lock spring   | 91. Lock spring          | 104. Bearing                 |
| 79. Cup plug              | 92. Threaded plug        | 105. Shifting guide          |
| 80. Roll pin              | 93. Drain plug           | 106. Screw                   |
| 81. Reverse lock assembly | 94. Rear housing         | 107. Bracket                 |
| 82. Intermediate housing  | 95. Oil seal             | 108. Bracket                 |

## Input Shaft / Mainshaft Assembly

FSO-2105 / FSO-2505 (4x2 and 4x4) Models




120. Input shaft bearing cup  
121. Input shaft bearing cone  
122. Input shaft  
123. 4th speed synchronizer cone  
124. Snap ring  
125. 4th speed synchronizer ring  
126. Mainshaft front bearing cone  
127. Snap ring 2.175 mm  
127. Snap ring 2.250 mm  
127. Snap ring 2.325 mm  
128. 3rd/4th speed synchronizer assembly  
129. Spring  
130. Key  
131. 3rd speed synchronizer ring  
132. Mainshaft 3rd speed gear cone  
133. Mainshaft 3rd speed gear  
134. Needle bearing

135. Mainshaft (4x2)  
135a. Mainshaft (4x4)  
136. Needle bearing  
137. Mainshaft 2nd speed gear  
138. Mainshaft 2nd speed gear cone  
139. 1st/2nd speed synchronizer inner ring  
140. 1st/2nd speed synchronizer middle ring  
141. 1st/2nd speed synchronizer outer ring  
142. 1st/2nd speed synchronizer assembly  
143. Key  
144. Mainshaft 1st speed gear  
145. Needle bearing  
146. Bushing  
147. Mainshaft intermediate bearing cone

148. Mainshaft intermediate bearing cup  
149. Shim 0.050 mm  
149. Shim 0.102 mm  
149. Shim 0.178 mm  
149. Shim 0.254 mm  
149. Shim 0.508 mm  
149. Shim 0.762 mm  
149. Shim 1.016 mm  
150. Mainshaft 5th speed gear  
151. Spacer  
152. Mainshaft reverse speed gear  
153. Ball bearing  
154. Nut  
155. Ball (4x2)  
156. Speedometer rotor (4x2)  
157. Snap ring (4x2)

## Countershaft Assembly

### FSO-2105 / FSO-2505 (4x2 and 4x4) Models



- |                                             |                                              |                                                        |
|---------------------------------------------|----------------------------------------------|--------------------------------------------------------|
| 160. Countershaft front bearing cup         | 165. Shim 0.508 mm                           | 174. Snap ring 2.365 mm                                |
| 161. Countershaft front bearing cone        | 165. Shim 0.762 mm                           | 174. Snap ring 2.290 mm                                |
| 162. Countershaft                           | 165. Shim 1.016 mm                           | 175. Countershaft reverse speed gear synchronizer ring |
| 163. Countershaft intermediate bearing cone | 166. Ball                                    | 176. Needle bearing                                    |
| 164. Countershaft intermediate bearing cup  | 167. 5th speed gear thrust washer            | 177. Countershaft reverse speed gear                   |
| 165. Shim 0.050 mm                          | 168. Needle bearing                          | 178. Ball                                              |
| 165. Shim 0.102 mm                          | 169. Countershaft 5th speed gear             | 179. Thrust washer                                     |
| 165. Shim 0.178 mm                          | 170. 5th speed synchronizer ring             | 180. Ball bearing                                      |
| 165. Shim 0.254 mm                          | 171. 5th/reverse speed synchronizer assembly | 181. Snap ring                                         |
|                                             | 172. Spring                                  |                                                        |
|                                             | 173. Key                                     |                                                        |
|                                             | 174. Snap ring 2.215 mm                      |                                                        |

## Lubrication

Proper lubrication procedure is the key to a good and complete maintenance program. If the oil is not doing its job, or if the oil level is ignored, all the other possible maintenance procedures will not be enough to keep the transmission running or to assure long transmission life.

Eaton transmissions are designed so that all the internal parts operate in an oil circulating bath, created by the motion of gears and shafts. Thus, all parts are properly lubricated if these procedures are closely followed:

1. Maintain proper oil level by inspecting it regularly.
2. Change oil regularly following the maintenance interval chart.
3. Use the recommended grade and type of oil.
4. Buy from a reputable dealer.

## Oil change and level inspection

Periodic transmission oil change eliminates possible bearing failures, ring wear and seizures, since the products of normal wear in service (tiny metal particles), which circulate in the transmission oil, are harmful to these parts. In addition, the oil changes chemically due to the repeated heating and cooling cycles of a transmission in use.

As a general guide, the following chart provides maintenance interval recommendation to level inspection and oil change.

**WARNING!** Always follow the vehicle manufacturer maintenance recommendation, which prevails over this chart.

**Recommended lubricant oil:** Eaton PS - 267

**Trademarks:** Eaton LCC2 – 3348887

### Highway use

|                       |   |                         |
|-----------------------|---|-------------------------|
| After first 50,000 km | → | Change transmission oil |
| Every 100,000 km      | → | Change transmission oil |

### Off-highway use

|                       |   |                         |
|-----------------------|---|-------------------------|
| After first 50,000 km | → | Change transmission oil |
| Every 50,000 km       | → | Change transmission oil |

## Draining

Drain transmission oil while the oil is warm. To drain oil, remove the magnetic drain plug.

Clean the drain plug before re-installing it.

## Refilling


## Oil level inspection

Before checking oil level, clean case area around filler plug and if necessary, add enough oil to maintain the proper oil level.

**WARNING!** Do not mix lubricant of different types and brands, as this may cause incompatibility issues.



Correct Oil Level



Incorrect Oil Level

FSO-2105/02

Clean case area around oil filler plug, remove the plug and refill the transmission until lubricant is level with the bottom of the filler plug hole.

**Note:** The amount of oil varies with the position of vehicle related to the ground and the installation angle of transmission. Before refilling, place vehicle on a flat and level surface. Fill up transmission until lubricant begins to leak through the filler plug.


**Lubricant oil volume:** 2.7 to 3.3 liters

## Gear shift lever pattern

FSO-2105 and FSO-2505 transmissions have 5 forward speeds and one reverse speed, all of them synchronized.

To shift speeds, follow the shift pattern shown by the illustration on the side.

A reverse gear shifting interlocking system prevents from accidental transmission shifting from 5th to reverse gear.



FSO-2105/03

### Tips for the driver

Always use the clutch to change gears. The incorrect use of the clutch may cause premature failures of the synchronizer assembly.

Always select a starting gear that will provide sufficient power (torque) for the vehicle's load and working conditions (terrain).

Never slam or jerk the gear shift lever to complete gear engagement.

Never leave the shift lever in the neutral position while going downhill.


## Power Flow

The transmission must efficiently transfer the engine's power or torque to the vehicle's driveline.


It is essential to know what takes place in the transmission during torque transfer when troubleshooting or making repairs.

### 1st, 2nd and 3rd Speeds


1. Torque from the engine is transferred to the transmission's input shaft.
2. From input shaft, the torque is transferred to the countershaft drive gear. In this way, input shaft and countershaft always run together.
3. The torque along the countershaft is delivered to all mainshaft gears assembled on bearings. These gears rotate free unless one gear is shifted.
4. When a gear is shifted, the torque is transferred from the corresponding engaged mainshaft gear, through the clutching teeth of the synchronizer assembly, to the mainshaft. Torque is, then, delivered along the mainshaft to the driveline components through output yoke.




### 1st Speed



### 2nd Speed



### 3rd Speed




## 4th Speed

The 4th speed gear is also named direct speed gear.

1. Torque from the engine is transferred to the transmission's input shaft that, despite driving the countershaft at the same time, transfers the torque directly to the mainshaft. The input shaft clutching teeth engage the clutching teeth of the 4th speed synchronizer unit which transfers the torque to the mainshaft.

The transmission's noise level in this speed is much reduced, since torque is delivered directly from one shaft to another and there are no gears under load.

## 4th Speed




## 5th and Reverse Speed


The 5th and reverse speed gears synchronizer unit is assembled on the countershaft, unlike the other speed synchronizers that are assembled on the mainshaft. By its turn, their corresponding gears on mainshaft are assembled fixed to the mainshaft.

1. With the 5th speed gear engaged, torque is transferred from countershaft to the mainshaft corresponding gear through the clutching teeth of the synchronizer hub.
2. When the reverse speed gear is engaged, torque is transferred from countershaft to the reverse idler gear, which changes the rotating direction, and then, from that gear to the mainshaft's reverse speed gear.


## 5th Speed



## Reverse Speed




The correct application of adhesives and sealing compounds is important to assure a proper assembly and to avoid leakages.




Tightening capscrews, plugs and nuts to the proper torque is important to prevent them from loosening and to avoid oil leakage, assuring a long transmission life. Additionally, apply the recommended adhesive to the threads.

**WARNING!** Always use a torque wrench to tight to the recommended torque.




FSO-2105/torque1



FSO-2105/torque2

| Item | Description                          | Thread | Torque N.m (Lb.ft) | Remarks                    |
|------|--------------------------------------|--------|--------------------|----------------------------|
| 1    | Gear shift control housing capscrews | M8     | 19-25 (14-19)      | Apply Eaton 677 to threads |
| 2    | Housing capscrews                    | M8     | 19-25 (14-19)      | Apply Eaton 677 to threads |



FSO-2105/torque3

| Item | Description                              | Thread           | Torque N.m (Lb.ft) | Remarks                                       |
|------|------------------------------------------|------------------|--------------------|-----------------------------------------------|
| 3    | Oil fill plug                            | 3/4" - 14 NPTF   | 40-47 (29-34)      | Apply Eaton E679 or 518 to threads            |
| 4    | Reverse light switch                     | M14              | 14-20 (10-15)      | Apply Eaton 680 to switch face                |
| 5    | Gear shift control housing threaded pin  | M12              | 10-16 (7-12)       | Apply Eaton 680 to pin face only              |
| 6    | Gear shift control housing threaded plug | M16              | 14-21 (10-15)      | Apply Eaton 680 to thrust face                |
| 7    | Shift control actuator plug              | M24              | 10-16 (7-12)       | Apply Eaton 680 to thrust face                |
| 8    | Speedometer sensor                       | 13-16" - 20 UNEF | 10-16 (7-12)       | Apply Eaton 677 to threads                    |
| 9    | Mainshaft nut                            | M37              | 217-270 (160-200)  | Lock the nut in position using a center punch |
| 10   | Oil drain plug                           | 3/4" - 14 NPTF   | 40-47 (29-34)      | Apply Eaton 680 or Eaton 679 to threads       |
| 11   | Threaded pin                             | M12              | 19-26 (14-19)      | Apply Eaton 680 to contact face with housing  |

## Precautions during disassembly and assembly



In order to prevent damage to transmission parts during initial gear movement, it is important when assembling the transmission, to lubricate gear bearings, needle bearings, non sealed bearings and all other parts under friction conditions, with the same transmission lubricant oil.

## Cleaning and handling

In order to completely clean the parts, wash them into a bath of solvent (kerosene, for instance), moving every part up and down slowly until all the old lubricant and foreign material have been dissolved.



Care must be taken to avoid skin rashes, fire hazard and vapor inhalation when using solvents.

## Non sealed bearings

Immerse the bearings in clean solvent. Move them up and down slowly in order to loosen the deposits. Dry the bearings by means of moisture free compressed-air. Repeat the operation until the bearings are thoroughly clean.



Never drive the air jet directly to bearings in order to rotate them in high speed. That can damage bearings.

## Synchronizer assemblies

Avoid bad handling of synchronizer assemblies. Either drops or bumps when disassembling or assembling may cause them to lock.

## Housings

Clean interior and exterior of cases, covers, etc., thoroughly. Cast parts may be cleaned in weak alkaline solution baths (we recommend a 7% soluble degreasing oil solution). The parts are to remain in the bath for the time it takes to become completely clean. The parts cleaned in alkaline solutions should be rinsed with clean water to remove any alkaline trace after cleaning process.



Care must be taken to avoid vapor inhalation and skin rashes when using alkaline solutions. Every cleaned part must be totally dried at once by means of moisture free compressed-air, or else, by means of a lint free soft cloth, not containing any abrasive material such as metal filings, contaminated oil or polishing compounds.

## Inspection

A thorough and careful inspection of each part is very important for the transmission life. The replacement of parts showing either wear or fatigue will avoid future expensive and foreseen failures.

## Gears, shafts and synchronizer assemblies

Whenever magna-flux is available, this process should be used to check the parts.

Check carefully gear teeth for wear, pitting, chipping and cracks. If gear teeth show areas where the case hardening is worn through or cracked, the gear should be replaced.

Check shafts for warping and excessive wear or damaged splines.

## Cases, covers, etc.

Make sure cases, covers, etc. are completely clean and that mounting surfaces and bearing bores are free from nicks or burrs. Check carefully every part for cracks, excessive wear or for any other condition that may cause oil leak or a future failure.

## Needle roller bearings

Check carefully every needle roller for wear, pitting or spalled areas to determine whether they are suitable for reuse or replacement. After inspection, dip the needle roller bearings in an oil bath and then wrap them in a lint free cloth or paper, so as to protect them until they are ready for assembling.

## Parts replacement

When replacement is necessary, use only genuine Eaton transmission parts to assure continued performance and extended life from the transmission. The use of either non-genuine or remanufactured parts, besides have not the factory's warranty, may lead to severe damage of the unit.

Since the cost of a new part is generally a small fraction of the total cost of downtime and labor, do not reuse a questionable part which could lead to additional repairs and expense soon after assembly.

To aid in determining the reuse or replacement of any transmission part, consideration should also be given to the unit's history, mileage, application, etc.




## Oil seals and snap ringselásticos

Any oil seal, snap ring, etc. damaged during maintenance, should be replaced by a new one. Replacement of oil seals and snap rings is cheaper when unit is disassembled than a premature overhaul to replace these parts in a future time.

An oil leakage through a worn seal may result in failures of other more expensive components of the transmission. The sealing elements should be handled carefully, particularly during assembly. Cuts, scratches or rolled up seal lips decrease the sealing efficiency.



Snap rings have proper assembling position due to the angle of their opening ends. The side with shorter opening should be faced towards the outside to facilitate the installation with pliers.



FSO-2105/04

The following chart presents some transmission malfunctions with their most common causes and possible solutions.

| Problem                              | Probable cause                                                      | Possible solution                                                | Reference                             |
|--------------------------------------|---------------------------------------------------------------------|------------------------------------------------------------------|---------------------------------------|
| Transmission noise when in neutral   | Incorrect idle speed adjustment                                     | Adjust idle speed                                                | As to vehicle's instruction manual    |
|                                      | Improper or damaged clutch disc                                     | Replace disc                                                     | As to vehicle's instruction manual    |
|                                      | Low lubricant level                                                 | Fill with recommended oil to the proper level                    | Recommended lubricant, in this manual |
|                                      | Contaminated lubricant                                              | Drain, clean transmission and replace with recommended lubricant | Recommended lubricant, in this manual |
|                                      | Worn or damaged gears or bearings                                   | Replace damaged parts                                            | As to this manual instructions        |
| Transmission noise with engaged gear | Improper or damaged clutch disc                                     | Replace disc                                                     | As to vehicle's instruction manual    |
|                                      | Low lubricant level                                                 | Fill with recommended oil to the proper level                    | Recommended lubricant, in this manual |
|                                      | Worn or damaged flywheel bushing or bearing                         | Replace                                                          | As to vehicle's instruction manual    |
|                                      | Vibration from other vehicle components (drive shaft, yoke, mounts) | Verify and repair                                                | As to vehicle's instruction manual    |
|                                      | Misalignment between engine and transmission                        | Correct or replace damaged parts                                 | Requires specific procedure           |
|                                      | Worn or damaged gears or bearings                                   | Replace damaged parts                                            | As to this manual instructions        |

| Problem       | Probable cause                                                                           | Possible solution               | Reference                                |
|---------------|------------------------------------------------------------------------------------------|---------------------------------|------------------------------------------|
| Hard shifting | Malfunction of clutch                                                                    | Verify and adjust clutch        | As to vehicle's instruction manual       |
|               | Worn or damaged flywheel bushing or bearing                                              | Replace                         | As to vehicle's instruction manual       |
|               | Non-recommended lubricant                                                                | Replace                         | Recommended lubricant, in this manual    |
|               | Worn or damaged gear shift lever components                                              | Replace damaged parts           | Gear shift lever housing, in this manual |
|               | Worn or damaged synchronizer rings                                                       | Replace rings                   | Synchronizer assemblies, in this manual  |
|               | Excessively worn or damaged synchronizer assemblies (springs, keys, sleeve or hub)       | Replace synchronizer assemblies | Synchronizer assemblies, in this manual  |
|               | Worn or damaged shifting system components (shift yokes, nylon pads, bars, shift blocks) | Replace worn or damaged parts   | As to this manual instructions           |
|               | Mainshaft or countershaft end play improperly                                            | Adjust end play                 | End play adjustment, in this manual      |

| Problem                 | Probable cause                                                                           | Possible solution               | Reference                               |
|-------------------------|------------------------------------------------------------------------------------------|---------------------------------|-----------------------------------------|
| Gears hard to disengage | Malfunction of clutch                                                                    | Verify and adjust clutch        | As to vehicle's instruction manual      |
|                         | Worn or damaged gear shift lever components                                              | Replace damaged parts           | Gear shift housing, in this manual      |
|                         | Excessively worn or damaged synchronizer assemblies (springs, keys, sleeve or hub)       | Replace synchronizer assemblies | Synchronizer assemblies, in this manual |
|                         | Worn or damaged shifting system components (shift yokes, nylon pads, bars, shift blocks) | Replace worn or damaged parts   | As to this manual instructions          |
|                         | Mainshaft or countershaft end play improperly adjusted                                   | Adjust end play                 | End play adjustment, in this manual     |
| Gear shift rubbing      | Malfunction of clutch                                                                    | Verify and adjust clutch        | As to vehicle's instruction manual      |
|                         | Malfunction of clutch linkage                                                            | Verify and adjust linkage       | As to vehicle's instruction manual      |
|                         | Worn or damaged flywheel bushing or bearing                                              | Replace                         | As to vehicle's instruction manual      |
|                         | Worn or damaged synchronizer rings                                                       | Replace rings                   | Synchronizer assemblies, in this manual |
|                         | Shift yoke nylon pads worn                                                               | Replace                         | Shift bars, in this manual              |

| Problem                        | Probable cause                                                                                       | Possible solution                               | Reference                               |
|--------------------------------|------------------------------------------------------------------------------------------------------|-------------------------------------------------|-----------------------------------------|
| Transmission slips out of gear | Gear shift lever console out of position, forcing the lever                                          | Adjust console                                  | As to vehicle's instruction manual      |
|                                | Worn or damaged synchronizer assemblies                                                              | Replace synchronizer assemblies                 | Synchronizer assemblies, in this manual |
|                                | 1st/2nd and 3rd/4th synchronizer hub swapped (anti-escape relief)                                    | Remove and assemble properly                    | Synchronizer , in this manual           |
|                                | Mainshaft or countershaft end play improperly adjusted                                               | Adjust end play                                 | End play adjustment, in this manual     |
|                                | Worn or damaged shifting system components (gear shift lever, shift yokes, bars, shift blocks, etc.) | Replace worn or damaged parts                   | As to this manual instructions          |
| Oil leak                       | Lubricant above proper level                                                                         | Correct to proper lubricant level               | Recommended lubricant, in this manual   |
|                                | Clogged breather                                                                                     | Verify an clean breather                        |                                         |
|                                | Worn or damaged oil seals                                                                            | Replace                                         | As to this manual instructions          |
|                                | Housing capscrews not properly tightened or lack of sealant                                          | Reassemble applying sealant and torque properly | As to this manual instructions          |
|                                | Cracked or damaged housings                                                                          | Replace or repair damaged parts                 | Requires specific procedure             |

| Problem          | Probable cause                                                | Possible solution                                        | Reference                             |
|------------------|---------------------------------------------------------------|----------------------------------------------------------|---------------------------------------|
| Bearing failures | Low lubricant level                                           | Fill with recommended oil to the proper level            | Recommended lubricant, in this manual |
|                  | Contaminated or non-recommended lubricant                     | Drain and replace with recommended lubricant             | Recommended lubricant, in this manual |
|                  | Transmission components assembled improperly                  | Reassemble                                               | As to this manual instructions        |
|                  | Mainshaft or countershaft end play improperly adjusted        | Adjust end play                                          | End play adjustment, in this manual   |
|                  | Bearings were not lubricated before assembling                | Replace damaged parts. Reassemble as to proper procedure | As to this manual instructions        |
| Double shifting  | Double gear shifting interlocking system improperly assembled | Reassemble properly                                      | As to this manual instructions        |

---

## Universal Tools


To properly servicing the FSO-2105 and FSO-2505 transmissions, it is recommended the use of following universal tools.

Tapered section snap ring pliers  
Constant section snap ring pliers  
T-handle 1/2" square drive x 12" long  
Ratchet-type wrench 1/2" square drive  
Allen wrench 12 mm  
Combination wrench open/box end 11 mm  
Combination wrench open/box end 13 mm  
Combination wrench open/box end 19 mm  
Open end wrench 16 x 17 mm  
Open end wrench 21 x 23 mm  
Screw driver 12"  
Hand scraper  
Ratchet extension 1/2" square drive x 10" long  
Ratchet extension 1/2" square drive x 4" long  
Magnet  
Sandpaper sheet 240 grit  
Ball pein hammer 300 g  
Plastic-tip hammer (soft mallet)  
Center punch  
Three-edged scraper  
Roll-pin punch 4 mm  
Roll-pin punch 6 mm  
Socket 1/2" square drive x 11 mm hex

## Essential Special Tools

Following tools are essential special tools, required for properly servicing the transmission. The non-use of these essential special tools, the higher are the chances of causing damage to the transmission during disassembly and assembly procedures.

| Illustration                                                                        | Tool Ref. | Description                                                               |
|-------------------------------------------------------------------------------------|-----------|---------------------------------------------------------------------------|
|    | E001009   | Rear housing oil seal installer (4x4)                                     |
|    | E001010   | Permaglide bushing installer                                              |
|    | E001013   | Universal driver for installers                                           |
|  | E001015   | Input shaft bearing cup installer                                         |
|  | E001016   | Mainshaft front bearing cup installer<br><b>Note:</b> Use with E001013    |
|  | E001039   | Countershaft front bearing cup installer<br><b>Note:</b> Use with E001013 |
|  | E001086   | Front seal installer                                                      |
|  | E003001   | Slide hammer (impact puler)                                               |

| Illustration                                                                         | Tool Ref. | Description                                |
|--------------------------------------------------------------------------------------|-----------|--------------------------------------------|
|    | E004002   | Slide hammer adapter end                   |
|    | E005003   | Pocket bearing cone puller                 |
|    | E006004   | Spline socket for input shaft - 23 splines |
|   | E006005   | Spline socket for input shaft - 10 splines |
|  | E007002   | Input shaft bearing cone puller            |
|  | E007007   | Mainshaft bearing cone puller              |
|  | E007008   | Countershaft bearing cone puller           |
|  | E010001   | Pocket bearing cone installer              |
|  | E010002   | Mainshaft rear bearing cone installer      |

| Illustration                                                                        | Tool Ref. | Description                                                                  |
|-------------------------------------------------------------------------------------|-----------|------------------------------------------------------------------------------|
|    | E010003   | Input shaft bearing cone installer                                           |
|    | E012001   | Universal puller jaw beam and center bolt                                    |
|    | E012002   | Puller jaws for removing bearings and gears<br><b>Note:</b> Use with E012001 |
|    | E012003   | Countershaft rear bearing cone puller                                        |
|   | E012009   | Front housing bearing cup puller                                             |
|  | E014020   | Adapter plate for transmission stand                                         |
|  | E017021   | Shift selector bar spring remover                                            |
|  | E018001   | Socket for removing the cam threaded actuator                                |


| Illustration                                                                        | Tool Ref. | Description                                                       |
|-------------------------------------------------------------------------------------|-----------|-------------------------------------------------------------------|
|    | E019001   | Socket for locking mainshaft nut (*)                              |
|   | E021001   | 5th/Reverse speed linked shift block retaining roll-pin installer |
|   | E021002   | 5th/Reverse speed linked shift block retaining roll-pin remover   |
|    | E022002   | Shift lug roll-pin remover and installer                          |
|  | E022011   | Universal bearing cup remover                                     |
|  | E023001   | Rear housing oil seal installer                                   |
|  | E030001   | Permaglide bushing remover<br><b>Note:</b> Use with E003001       |


(\*) **Note:** This tool is used as an option for locking the transmission mainshaft, allowing transmission disassembly and assembly by one mechanic only. The tool allows using transmission gear ratio as a means to help in removing and installing the mainshaft nut.

Other complementary tools are provided to make transmission service easier to be carried out. A complete list of these tools can be seen below, in this manual.

## Complementary Tools


| Illustration                                                                        | Tool Ref. | Description                                                                            |
|-------------------------------------------------------------------------------------|-----------|----------------------------------------------------------------------------------------|
|    | E001020   | Front housing expansion plug installer punch                                           |
|    | E001033   | Front bearing cover seal installer<br><b>Note:</b> Use with E001013                    |
|    | E001034   | Rear seal installer<br><b>Application:</b> All 4x4 vehicles                            |
|    | E001035   | Intermediate housing mainshaft bearing cup remover<br><b>Note:</b> Use with E001037    |
|  | E001036   | Intermediate housing countershaft bearing cup remover<br><b>Note:</b> Use with E001037 |
|  | E001038   | Intermediate housing mainshaft bearing cup installer<br><b>Note:</b> Use with E001037  |
|  | E001044   | 1st/2nd, 3rd/4th and 5th/Reverse speed yoke bar roll-pin punch                         |
|  | E001045   | Shift lug roll-pin punch                                                               |

| Illustration                                                                         | Tool Ref. | Description                                                     |
|--------------------------------------------------------------------------------------|-----------|-----------------------------------------------------------------|
|    | E005005   | Thread cutter                                                   |
|    | E006002   | Special socket 30 mm                                            |
|    | E006006   | Special wrench 54 mm                                            |
|     | E006007   | Mainshaft lock - 27 splines<br><b>Note:</b> Use with E014010    |
|   | E006017   | Mainshaft nut wrench                                            |
|  | E008001   | Pry bar for measuring end play                                  |
|  | E009005   | Plate for supporting the dial indicator gauge                   |
|  | E010010   | Countershaft bearing cone installer                             |
|   | E014010   | Base for locking the mainshaft<br><b>Note:</b> Use with E006007 |

| Illustration                                                                      | Tool Ref. | Description                                                                                                  |
|-----------------------------------------------------------------------------------|-----------|--------------------------------------------------------------------------------------------------------------|
|  | E014011   | Adapter plate for transmission stand                                                                         |
|  | E014019   | Transmission overhauling stand<br><b>Option:</b> Without reduction, with reduction or electric stand         |
|  | E024001   | Intermediate housing bearing cup puller/installer support<br><b>Note:</b> Use with E001016 and E001039 tools |


| Illustration                                                                       | Tool Ref. | Description        |
|------------------------------------------------------------------------------------|-----------|--------------------|
|  | E027001   | Oil seal installer |
|  | E028011   | Oil seal remover   |

## Application Flex 2.4L SOHC 4x2






## Application Flex 2.4L SOHC 4x4




# FSO-2105 Model


## Application Flex 2.4L SOHC 4x4

PAGE 2/2



**Application Diesel 4x2 2.5 2.8**

**Application Diesel 4x2 2.5 2.8**




## Application Diesel 4x4 2.5 2.8





## Application HFV6 4x2





## Application HFV6 4x4





## Gear shift lever housing disassembly

Replace all internal parts, but gear shift lever. Inspect the gear shift lever for wear and replace it if worn. In case the housing should be replaced, get a complete assembly from your dealer.

1. Remove the four retaining capscrews from the gear shift lever housing and remove gear shift lever housing assembly from the transmission.




2. Remove the boot.



3. From the housing, remove locating pin, spring and threaded plug.




4. From the housing, remove the two threaded pins.



5. Remove gear shift lever by hands and remove the pivot pin from the lever.



6. Remove gear shift lever pivoting support and thrust washers.




7. Remove the nylon bushing from the gear shift lever lower end.



### Gear shift lever housing assembly

1. Install thrust washers into the gear shift lever housing.



2. Install the nylon bushing, gear shift lever pivoting support and the thrust washers onto the lever pivoting support.


**Note:** Use grease to hold thrust washers in position.




3. With the hands, install gear shift lever in the gear shift lever housing.




4. Install the two threaded pins on gear shift lever housing.



8. Place the shock-absorbing rubber gasket onto the rear housing.



5. Install the locating pin, spring and threaded plug on gear shift lever housing.



9. Install the four shock-absorbing bushings with the four support spacers onto gear shift lever housing.


**Note:** Install support spacer with its chamfered face down.




6. Install the boot.



10. Apply multi-purpose grease on the shift lever end and install the nylon bushing pushing it with the fingers.



7. Place transmission horizontal and install the four washers on rear housing.




11. Install the gear shift lever housing assembly on the shock-absorbing rubber gasket on the transmission.



12. Install the four gear shift lever housing capscrews and tighten them to the specified torque.

**Note:** Apply Eaton 677 on threads.

Torque = 19-25 N.m (14-19 Lb.ft)



## Rear Section Disassembly


1. Remove the gear shift lever housing assembly from the transmission. Refer to "Gear Shift Lever Housing", in this manual.




2. Place transmission with rear case facing up.
3. Shift transmission into Neutral through shift bars.

**WARNING!** Remove the shift lug roll pin BEFORE removing the threaded actuator of shifting cam.


4. Using the special tool E022002, remove the shift lug roll pin by pushing it forward into the housing.




5. Remove the plug, spring and spherical actuator pin of the cam threaded actuator with the special socket E018001.



6. Remove the thirteen capscrews securing the rear case to the intermediate housing.
7. Using a rubber or plastic hammer to break the gasket seal, carefully hit case to detach the rear case from the intermediate housing. Remove rear case by pulling it upwards.




8. Remove the speedometer rotor snap ring.



9. Remove the speedometer rotor pulling it upwards.




10. Remove the rotor retaining ball from the mainshaft.



11. Lock mainshaft using tool E019001 (socket for locking mainshaft nut). For this purpose, install the special socket hexagonal hole on the mainshaft nut as shown in the figure and rotate the shaft until the two holes on the socket match to the nearest two holes on the housing.


Tighten the special socket to the housing with two housing's capscrews.

**WARNING!** Be careful do not overtighten capscrews or leave them loose in order to avoid damage to the aluminum housing.




12. Shift transmission into 1st gear using the shift yoke bars.

**Note:** With no gear shift lever housing installed, the gear shift lever pattern is inverted.



13. Place transmission horizontal and install the special socket E006004 or E006005, depending on the input shaft spline type, onto the input shaft. Using a suitable wrench, rotate the shaft counterclockwise for loosening the mainshaft nut.



14. Remove the special tools.

**Note:** As an option to remove the mainshaft nut, the tool E014010 may be used to lock the mainshaft and the tool E006006 used to remove the nut (refer to "Tool Information", in this manual).

15. Remove the countershaft snap ring.



16. Using special tools E012001 and E012003, remove the countershaft ball bearing.




20. Remove the reverse idler gear needle bearing.



17. Remove the bearing thrust washer.

**Note:** The thrust washer has a retaining ball (see figure), which should also be removed.



21. Remove the reverse gear from the countershaft.




18. Using special tools E012001 and E012002, remove the reverse gear and the ball bearing together from the mainshaft by pulling them off.



22. Remove the reverse gear needle bearing and spacer from the countershaft.




19. Remove the reverse idler gear.




23. Remove the reverse speed synchronizer ring.



24. Remove pivot pins of the 5th/reverse speed shift yoke.



25. Push the 5th/reverse speed shift yoke towards the synchronizer in order to loosen it from the linked shift block. Lift the yoke end and remove the yoke by pulling it upwards.




26. Remove the 5th/reverse speed synchronizer hub snap ring from the countershaft.



27. Remove the 5th/reverse speed synchronizer assembly.




28. Remove the 5th speed synchronizer ring.



29. Remove the 5th speed gear from the countershaft.




30. Remove the 5th speed gear needle bearing from the countershaft.




31. Remove the 5th speed gear thrust washer from the countershaft.



32. Remove the retaining ball of the 5th speed gear thrust washer from the countershaft.




36. Remove the 5th/reverse speed linked shift block.



33. Remove the 5th speed gear from the mainshaft.



34. Remove the reverse light switch.



35. Remove the 5th/reverse speed linked shift block retaining roll pin.

**Note:** Use the special pin punch E021002 and the special reverse light switch thread protector bushing E021001.



## Oil Seal Replacement

### Removal

1. Use a pry bar or screwdriver to remove the oil seal.

**Note:** The removed oil seal should not be reused.



### Installation

**Note:** If removed, always replace the oil seal.


1. Coat the new seal lips with the recommended grease.
2. Position the seal on the rear case and install it in the bore using the proper tool.

**Note:** Use the proper device for the transmission (refer to "Special Tools", in this manual).





## Rear Section Assembly

1. Place transmission with the rear section facing up.
2. Install the 5th/reverse linked shift block.




3. Install the 5th/reverse linked shift block retaining roll pin using the recommended special pin E0021001 punch and the reverse light switch thread protector bushing.

**Note:** Replace the roll pin by a new one.



4. Install the reverse light switch.


**Note:** Apply Eaton 680 or Eaton 679 sealant to the switch threads.



5. Install the 5th speed gear on the mainshaft.



6. Install the retaining ball of the countershaft 5th speed gear thrust washer on the countershaft. Apply grease to hold the ball in place.



7. Install the 5th speed gear thrust washer on the countershaft. Make sure to fit correctly the retaining ball into the washer slot.

**Note:** Install the thrust washer counterbore side outward (facing the needle bearing).



8. Install the 5th speed gear needle bearing on the countershaft.



9. Install the 5th speed gear on the countershaft.



10. Install the 5th speed ring synchronizer on the countershaft..

**Note:** The 5th speed synchronizer ring is NOT coated with EFM II and is smaller than the other rings.




11. Install the 5th/reverse synchronizer assembly on the countershaft. Make sure it is installed in the proper position.

**Note:** Both the synchronizer sleeve sharp end and the hub anti-escape relief should be installed facing the 5th speed gear (refer to "Synchronizer Assemblies", in this manual).

Make sure to properly slide the synchronizer ring lugs into the hub key slots.




12. Install the 5th/reverse synchronizer hub snap ring on the countershaft.




13. Install the reverse speed synchronizer ring.

**Note:** The reverse synchronizer ring IS coated with EFM II and is smaller than the other rings.



14. If necessary, replace the 5th/reverse shift yoke nylon pads.






15. Install the 5th/reverse shift yoke in synchronizer sleeve groove. Pull the yoke backwards until engaging with the linked shift block.



16. Install the two pivot pins of 5th/reverse shift yoke.

**Note:** Apply Eaton 677 sealant to pin threads.

Torque = 10-16 N.m (7-12 Lb.ft)




17. Install the reverse gear needle bearing on the countershaft.



**Note:** Use 1 (one) Eaton P/N 3348906 bearing.



18. Install the reverse gear on the countershaft.



19. Install the reverse idler gear needle bearing on the idler shaft.




20. Install the reverse idler gear on the shaft with the most protruding side of the hub facing the housing outside.



21. Install the reverse gear with the rear ball bearing together on the mainshaft with the most protruding side of the hub facing the housing inside.



22. Install the ball bearing thrust washer on the countershaft.



**Note:** The thrust washer has a retaining ball, which should be installed with the washer.



23. Install the countershaft rear ball bearing using special tools E012001 and E012003.



24. Install the countershaft snap ring.

**Note:** Use a new brand snap ring when reassembling the transmission.



25. Install the mainshaft nut. Following are instructions on how to lock the mainshaft and to tighten the nut.


**Note:** Use a new brand nut when reassembling the transmission.



26. Lock mainshaft using tool E019001 (socket for locking mainshaft nut). For this purpose, install the special socket hexagonal hole on the mainshaft as shown in the figure and rotate the shaft until the two holes on the socket match to the nearest two holes on the housing.


Tighten the special socket to the housing with two housing's capscrews.

**WARNING!** Be careful do not overtighten capscrews or leave them loose in order to avoid damage to the aluminum housing.




27. Shift transmission into 1st gear using the shift yoke bars.

**Note:** With no gear shift lever housing installed, the gear shift lever pattern is inverted.



28. Place transmission horizontal and install the special socket E006004 or E006005, depending on the input shaft spline type, onto the input shaft. Using a torque wrench, rotate the shaft clockwise for tightening the mainshaft nut to the torque as specified below.

**WARNING!** When applying torque to the mainshaft nut, it is MANDATORY to consider the 1st speed gear reduction ratio. Follow the instructions supplied with the tool and described below.



To tighten the nut, check the table below for the torque to be applied on the tool using the 1st speed reduction ratio.

| Transmission | Gear ratio at 1st speed<br>Torque to be applied |
|--------------|-------------------------------------------------|
| FSO 2105A    | 4.473 49 to 60 N.m                              |
| FSO 2505A/B  | 4.079 54 to 66 N.m                              |

**WARNING!** Check the vehicle's Manual for the transmission specifications to make sure the 1st speed gear ratio matches to the gear ratio shown in the table above. If not, calculate the torque amount as follows.

- Specified torque for the nut: 217 to 270 N.m

Example:

*Transmission 1st gear ratio: 4.473*


- Divide 217 by 4.473 and round off to the higher nearest integer:  
 $217 \div 4.473 = 48.51$  use 49
- Divide 270 by 4,079 and round off to the lower nearest integer:  
 $270 \div 4.473 = 60.36$  use 60

Torque to be applied on the tool: 49 to 60 N.m

29. Remove the tools.

**Note:** As an option for the above procedure, the special tool E014010 may be used for locking the mainshaft and the tool E006006 to tighten the nut. In this case, the torque is applied directly to the nut and the specified amount is 217 to 270 N.m.

30. Lock the mainshaft nut using a center punch.




31. Install the retaining ball that locks the speedometer rotor on the mainshaft and then install the rotor. Install the rotor snap ring.


**Note:** Use grease to hold the ball in place.



32. Apply Eaton 680 gasket compound to the rear cover mounting surface with the intermediate housing.




33. Install the rear cover.




34. Install the thirteen retaining capscrews of rear case to the intermediate housing. Tighten capscrews crosswise to the proper torque.

**Note:** Apply Eaton 677 sealant to capscrew threads.

Torque = 19-25 N.m (14-19 lb.ft)




37. Align the shift lug with the gear shift bar matching the roll pin holes and install the retaining roll pin using tool E001045.



35. Install the speedometer sensor.

**Note:** Apply Eaton 680 or Eaton 679 sealant to sensor threads


Torque = 10-16 N.m (7-12 lb.ft)



38. Install the gear shift lever housing assembly onto the transmission. Refer to "Gear Shift Lever Housing", in this manual.




36. Install the plug, spring and spherical actuator pin of the cam threaded actuator, using the special socket E018001.



## Front Section Disassembly


1. Disassemble the rear section (refer to "Rear Section Disassembly").
2. Shift transmission into Neutral through shift bars.
3. With the special socket E018001, remove the shift positioning plug, spring and ball.



4. Remove the thirteen capscrews securing the intermediate housing to the front housing.




5. From inside the front housing, remove capscrews securing the front housing to the intermediate housing.




6. Remove the intermediate housing.

**Note:** Use pry bars between the housing special bosses provided to detach the intermediate housing. If necessary, carefully hit housing's capscrews area with a rubber or plastic hammer to brake the gasket seal and detach the housing.

**WARNING!** Do not support pry bar on housing's contact surface in order to not damage the sealing surface.



7. Pull the 5th/reverse yoke bar upwards and remove it.




8. Rotate the shift selector bar counterclockwise and remove it pulling the bar upwards.




9. Remove the 1st/2nd shift yoke roll pin.

**Note:** Use the 4 mm diameter roll-pin punch E021002.



10. Hold the 1st/2nd shift yoke in its place on synchronizer groove and pull the yoke bar upwards. When the bar lower end rises over the housing surface (see detail), remove the bar and shift yoke assembly.



11. Simultaneously, remove from the housing the remaining assemblies of mainshaft, countershaft, 3rd/4th bar and shift yoke and input shaft, while grasping them all together and pulling them upwards.




12. Take the assemblies apart.


## Mainshaft

### Disassembly

1. Using the Pocket bearing puller E005003, remove the front bearing cone from mainshaft.



2. Remove the 3rd/4th synchronizer hub retaining snap ring.




3. Place mainshaft in the press, using either 2nd or 4th speed gear as a base.
4. Press mainshaft through and remove the set of components up to the rear bearing cone.



**WARNING!** Be careful NOT to use mainshaft flange as a pressing base when using the 3rd speed gear.

5. Turn the mainshaft over in the press and use the 3rd speed gear as a base.
6. Press mainshaft and remove the 3rd/4th synchronizer assembly, 3rd speed gear and the needle bearing.




### Assembly



1. Install the 2nd speed gear needle bearing.



2. Install the 2nd speed gear.




3. Install the 2nd speed synchronizer rings, inner, middle and outer, in this order. Make sure they are installed in the proper position. The inner ring lugs must be facing to the synchronizer hub while the middle ring lugs must fit into the holes in the gear cone. Refer to “Synchroizer Assemblies” later in this manual.




4. Install the 1st/2nd speed synchronizer assembly. Make sure it is installed in the proper position.


**WARNING!** Both the largest chamfer of the synchronizer sleeve and the most protruding side of the hub of the 1st/2nd speed synchronizer must face the 1st speed gear (refer to “Synchroizer Assemblies”).



5. Align the center of the recess in the synchronizer sleeve teeth with the center of the key at the three positions and install the synchronizer sleeve.



6. Install the 1st speed outer and middle synchronizer rings. Make sure they are installed in the proper position. Refer to “Synchroizer Assemblies” later in this manual.




7. Install the 1st speed inner synchronizer ring. Make sure ring lugs fit into the hub slots.




8. Install the 1st speed gear, fitting the holes in the gear cone on the middle synchronizer ring lugs.




9. Install the 1st speed gear needle bearing.



10. Install the 1st speed gear bushing.



11. Install the rear bearing cone on the mainshaft.



12. Using the E010002 special tool, press the late installed set of components onto the mainshaft. Make sure to align the synchronizer ring lugs with hub key slots to properly fit.

**WARNING!** Apply force to bearing inner race. NEVER apply force to the bearing cage. Do NOT use the shaft flange as a pressing base.




13. Check if the pressing procedure has been successful: disengage the synchronizer and put it in an intermediate position between 1st and 2nd speed gears. The gears in this condition should rotate freely.
14. Turn the mainshaft over and install the 3rd speed gear needle bearing.



15. Install the 3rd speed gear.




16. Install the 3rd speed synchronizer ring.



17. Install the 3rd/4th speed synchronizer assembly. Make sure it is installed in the proper position.

**WARNING!** Both the largest chamfer of the synchronizer sleeve and the most protruding side of the hub of the 3rd/4th speed synchronizer must face the 3rd speed gear (refer to “Synchroizer Assemblies”).


The 3rd/4th speed synchronizer hub does have an anti-escape relief, which must face the 3rd speed gear (refer to “Synchroizer Assemblies”).



18. Using special tools E010001 and 010002, press the late installed set of components onto the mainshaft. Make sure to align the synchronizer ring lugs with hub key slots to properly fit.

**WARNING!** Apply force to bearing inner race. NEVER apply force to the bearing cage.

19. Check if the pressing procedure has been successful: disengage the synchronizer and put it in an intermediate position between 3rd and 4th speed gears. The gears in this condition should rotate freely.



20. Install the 3rd/4th speed synchronizer hub retaining snap ring.



21. Position the front bearing cone on the mainshaft.  
22. Using the special tool E010001, press the front bearing cone.

**WARNING!** Apply force to bearing inner race. NEVER apply force to the bearing cage.




## Countershaft


### Disassembly

**WARNING!** Do NOT use the bearing roller cage as a pressing base.

1. Place the countershaft in the press with the front bearing facing up. Use the bearing inner race as a base by using the special support E007008.



2. Use a tubular tool and press the countershaft through the front bearing to remove the bearing.



3. Turn the countershaft over and use the rear bearing cone as a pressing base by using the E007008 special device.



4. Press the countershaft through the rear bearing and remove the bearing.



### Assembly

1. Position both the front and the rear bearing cones on the countershaft.



2. Use two tubes of the appropriate size and diameter or use the special tool E010010 and place the countershaft in the press, using the inner races of those two bearings as a base.

**WARNING!** NEVER use the bearing roller cage as a pressing base.




3. Press both bearings until they rest against the shaft shoulders.

## Input Shaft


### Disassembly

**WARNING!** Do NOT use the bearing roller cage as a pressing base.


1. Place the input shaft in the press with bearing facing up. Use the bearing inner race as a base by using the special support E007002.



2. Press the input shaft through the bearing and remove the bearing.




2. With the synchronizer side down, place the input shaft on a base. Be careful not to damage the synchronizer cone.




3. Using the bearing inner race as a base, press the bearing assembly with the appropriate tubular tool, until the race shoulder be against the shaft face.

**WARNING!** Apply force to bearing inner race. NEVER apply force to the bearing cage.



### Assembly

1. Position the bearing cone on the input shaft.




## Shift Yoke Bars


### Disassembly

1. Remove the retaining roll pins and remove the parts from the shift bars.


**Note:** Use the 4 mm diameter E021002 pin punch.



2. If necessary, replace the shift yoke permaglide bushings. After installing the bushing, use a punch to lock the bushing in the bushing bore. Be careful not to damage neither the bushing nor the shift yoke.




3. If necessary, replace the shift yoke nylon pads.




### 1st/2nd and 3rd/4th Speed Yoke Bar Assembly

1. Make sure the shift block is properly positioned regarding the notch at the yoke bar end and install the shift block on the yoke bar.



2. Make sure the 3rd/4th speed shift yoke is properly positioned regarding the notch at the yoke bar end and install the shift yoke on the yoke bar.



3. Align the shift yoke with the yoke bar matching the roll-pin holes and install the retaining roll pin. Using tool E001044, push the roll pin until it is flush with yoke hub.


**Note:** Replace the roll pin with a new one.

4. Align the shift block with the yoke bar matching the roll pin holes and install the retaining roll pin. Using tool E001044, push the roll pin until it is flush with shift block hub.

**Note:** Replace the roll pin with a new one.

## Shift Selector Bar Assembly

1. The shift selector block is assembled on the main bar with two retaining roll pins and therefore can only be installed on one side of this bar.



197


2. Install the shift selector block on the shift bar.
3. Align the selector block with the shift bar matching the roll-pin holes and install the retaining roll pins. Using tool E001045, push the roll pin until it is flush with selector block hub.

**Note:** Replace the roll pins with new ones.




576

4. Install the spring supporting washers on both sides of the selector block.




580

5. Install springs and supporting bushings.



585


6. Install the retaining snap rings of the selector block using the E017021 special device.



602

## 5th/reverse Yoke Bar Assembly


1. Make sure the shift block is properly positioned regarding the notch at the yoke bar end and install the shift block on the yoke bar. Notice that the opposite bar end also has a notch, shifted 180° from the other, and a hole.



624

2. Align the shift block with the shift bar matching the roll-pin holes and install the retaining roll pin. Using tool E001044, push the roll pin until it is flush with shift block hub.

**Note:** Replace the roll pin by a new one.




## Expansion Plugs

Some through holes in housings are drilled for machining purpose only and must be blocked later by using cup-type metal expansion plugs.


During the transmission life, it is possible to happen that some of those plugs should be removed and reinstalled when servicing the unit.

## Removal

1. In the housing, locate the expansion plug that should be removed. Use the special device E005005 and make a thread in the plug.



2. Use one retaining capscrew removed from the housing and insert it into the plug, threading it until it stays firmly in place.




3. Use the impact puller E003001 and adapter E004002 to remove the capscrew and the plug comes along.



## Installation


**WARNING!** Always replace the removed plug with a new one to prevent leaks.

1. With a clean rag and solvent, clean the plug hole and remove any remaining sealant compound. Do not use sandpaper.




2. Apply sealant to the new plug and insert it into the hole using the hands to guide the plug.

**Note:** Apply Eaton 677 to plugs.



3. Using the special tool E001020, hit with a hammer to force the plug into the plug bore until the plug penetrates 2 mm below the plug bore top, that is the proper plug depth.



## Permaglide Bushing

### Removal

1. Inspect bushing and replace if worn.

**Note:** Inspect other transmission bushing too. The pictures here show only the front housing bushing, however the procedure is the same for all other transmission permaglide bushing.

**Note:** Use special tools E003001 and E030001.



2. Place a punch against the bushing outer diameter through the lubrication hole.




3. Hit the punch and deform the bushing inward as shown.



4. Use pliers and pull the bushing out from the bushing bore.

### Installation

1. Place the bushing on the special tool E001010.




2. Position the bushing in the bushing bore and install the bushing by hitting the tool until it rest against the housing. This condition gives the proper bushing depth.
3. Use a center punch and lock the bushing by punching the housing material in four positions around the bushing bore.

**WARNING!** When locking the bushing, be careful not to damage the bushing itself.




4. Apply a thin coating of recommended grease to the bushing inner diameter.




## Reverse Shifting Interlocking System

### Description

The reverse shifting interlocking mechanism prevents the driver from shifting accidentally into reverse speed when downshifting from 5th to 4th speed.




The mechanism comprises a lock device installed in the front case working together with the shift selector bar. When the 5th/ reverse speed yoke bar is positioned into 5th speed, the lock mechanism is actuated by the spring avoiding the return of the bar and so preventing the reverse speed from being straight shifted. To deactivate the locking mechanism, just gearshift to neutral and then to reverse speed.



## Disassembly


1. Remove the metal expansion plug from housing hole where is located the interlocking mechanism retaining roll pin.

**Note:** Refer to “Expansion Plugs” in this manual for instructions.



2. Through the housing hole, remove the roll pin.

**Note:** Use a 4 mm diameter roll-pin punch.



3. Pull the interlock pin upward and remove the mechanism assembly.



## Assembly

1. Align the roll pin hole on the interlock pin with the corresponding hole on the housing and then install the interlocking mechanism into the interlock pin bore.




2. Give the spring as much as the tension you can by winding the spring on the pin and then set its free end in the housing hole.




3. Install a new roll pin.

**Note:** Replace the roll pin by a new one and use a 4 mm diameter roll-pin punch.



4. Install a new expansion plug in the housing hole.


**Note:** Refer to “Expansion Plugs” in this manual for instructions.



## Double Gear Shifting Interlocking System

### Description


The double gear shifting interlocking mechanism prevents shifting into two gears at the same time.



Such mechanism comprises one interlock pin and five interlock balls.

**WARNING!** One interlock ball has an 8.0 mm diameter while the other four interlock balls have a 9.5 mm diameter. A larger ball does not install into the smallest interlock bore.

When shifting any of the speed gears, the yoke bar of this specific speed pushes away the corresponding ball, displacing the remaining balls and locking the other yoke bars into the neutral position.



**WARNING!** Be careful when removing the yoke bars. Interlock balls may drop into the bar bores. Keep a close watch on the interlock balls when disassembling and assembling the transmission.

## Disassembly

1. Remove the metal expansion plug near to the 5th/reverse speed yoke bar.

**Note:** Refer to “Expansion Plugs” in this manual for instructions.



2. Push the interlock pin to the opposite side in order the interlock balls drop from their bores.



3. Displace the interlock pin towards the removed expansion plug hole and remove the pin through the housing hole.




## Assembly

1. Apply grease to interlock bores to keep the balls in place.
2. Install three interlock balls aligned from the 3rd/4th yoke bar bore and install the smallest ball (8.0 mm diameter) located in the 1st/2nd yoke bar bore.



3. Install the interlock pin through the housing hole whose expansion plug was removed before.



4. Install the interlock ball located in the 5th/reverse yoke bar bore.



5. Install a new expansion plug in the housing hole.

**Note:** Refer to “Expansion Plugs” in this manual for instructions.



## Input Shaft Bearing Cup

### Removal

1. Place the front housing properly supported with the input shaft bearing cup side up.
2. Use the bearing cup puller E012009 and remove the bearing cup from the bearing bore.



### Installation

1. Support properly the front housing with bearing bore side up.
2. Prior installing the bearing cup, carefully clean bearing cup and bore.
3. Using the driver and special installer 001013 and E001015, drive the bearing cup into the bearing bore until cup seats on the bottom.



## Input Shaft Oil Baffle and Oil Seal

### Removal

1. Remove the input shaft oil baffle and oil seal using some sort of pry bar or use a pin punch to push them out of their bores by hitting.




3. Install the input shaft oil baffle, observing its correct mounting position.



### Installation

**Note:** Replace baffle and seal with new ones whenever they are removed.


1. Coat the new seal lips with the recommended grease.
2. Install the input shaft oil seal in its bore using the special tool E001086 to guide the seal properly.



## Countershaft Front Bearing Cup

### Removal

1. Place the front housing properly supported with the countershaft bearing cup side up.
2. Use special puller E012009 fitted under the bearing cup counterbore at the cup bottom and remove the bearing cup.



### Installation

1. Support properly the front housing with bearing bore side up.
2. Prior to installing the bearing cup, carefully clean both bearing bore and cup.
3. Use the E001039 special tool and drive the bearing cup into the bearing bore until cup is completely seated on the bottom.


**Note:** Use with the special tool E001013.




## Mainshaft and Countershaft Rear Bearing Cups

### Removal

1. Place the intermediate housing properly supported with the bearing cup removing side down.
2. Use special devices E001035 and E001036 along with the support E024001 and remove mainshaft and countershaft rear bearing cups from the bearing bores.



3. Remove all existing shims from mainshaft and countershaft bearing bores.



### Installation

1. Support properly the intermediate housing with bearing bore side up.
2. Prior to installing the bearing cup, carefully clean both bearing bore and cup.

**WARNING!** Dirt between the bearing cup and the bearing bore can lead to axial clearance (end play) adjustment error.

3. Install the bearing cups without any shim before adjusting the transmission end play.

**WARNING!** Refer to “End Play Adjustment” later in this manual.

4. Use special devices E001016 and E001039 along with the support E024001 and install the mainshaft and countershaft rear bearing cups, driving the bearing cup into the bearing bore until it is completely seated on the bottom.



## Synchronizer Assemblies

**WARNING!** When repairing synchronizer assemblies, do not replace a single part only. Always replace the whole assembly. If would be necessary to replace one synchronizer ring, always replace the transmission synchronizer ring set.

### Description


Synchronizers and synchronizer rings together are responsible for engaging the transmission gears. To properly perform their function, it is important to be correctly assembled and installed in the transmission. Therefore, we recommend you to read carefully the instructions below.

This transmission model has three synchronizer assembly types, as described below.

**WARNING!** Before installing synchronizer assemblies on shafts, is very important to be acquainted with their design features and be able to identify them as well.


### 1st/2nd Speed Synchronizer

The 1st/2nd speed synchronizer has keys assembled with balls and does not use springs.



Both the 1st and the 2nd speed synchronizer rings are composed of 3 (three) rings: one inner ring, one middle and one outer ring. The outer ring has the special EFM II coating.

**Note:** The EFM II is a special coating used in some synchronizer rings to increase its lifetime.




### Disassembly

1. With the hands, remove the synchronizer sleeve from the hub.




- Slide the keys with balls out from the synchronizer hub slots and remove them.




## Assembly

- Install the key into the key groove in the synchronizer hub depressing the ball. Repeat this procedure for the three keys.



- The center of the key must coincide with the center of the recess in the synchronizer sleeve teeth, at the three positions. With that in mind, align the synchronizer sleeve with the synchronizer hub.




- With the hands, fit the synchronizer sleeve onto the hub pushing the sleeve downward.




## Installation


- Install the synchronizer hub with its most protruding side facing to the 1st speed gear.
- Install the synchronizer sleeve with its chamfered side facing to the same side of the most protruding side of the synchronizer hub.



- The outer synchronizer ring must be installed with the teeth side facing to the gear and the ring lugs must slide into the synchronizer hub key slots.




4. The middle synchronizer ring is installed with lugs facing to the gear and should fit into gear cone holes.




### 3rd/4th Speed Synchronizer

Both the 3rd and the 4th speed synchronizer rings have the special EFM II coating.



5. The inner synchronizer ring is installed with lugs facing to the synchronizer hub and should fit into hub slots.



### Disassembly

1. With the hands, remove the synchronizer sleeve from the hub.



- Slide the keys and springs out from the synchronizer hub slots and remove them.



- To help when assembling, position a synchronizer ring at the sleeve opposite side and insert the ring lugs into the synchronizer hub key slots.



## Assembly

- Place the spring inside the key hole, depress the spring and slide spring and key together into the synchronizer hub. Repeat this procedure for the three keys.



- Place the assembly on the bench with the synchronizer ring facing down.
- With the hands, install the synchronizer sleeve on the synchronizer hub by forcing the sleeve downwards.




- The center of the key must coincide with the center of the recess in the synchronizer sleeve teeth, at the three positions. With that in mind, align the synchronizer sleeve with the synchronizer hub.



## Installation

- Install the synchronizer hub with its most protruding side facing to the 3rd speed gear.
- Install the synchronizer sleeve with its chamfered side facing to the same side of the most protruding side of the synchronizer hub.




### 5th/Reverse Speed Synchronizer

The 5th/reverse speed synchronizer hub has the letter "R" stamped on its body.



412




### Disassembly and Assembly

The procedure for disassembling and assembling the 5th/reverse speed synchronizer is the same as described above for the 3rd and 4th speed synchronizer.

### Installation


The teeth ends of the 5th/reverse speed synchronizer sleeve have one side rounded and the other side sharp ended. Install the 5th/reverse synchronizer assembly with the sleeve teeth rounded end facing to the reverse gear and the sharp end facing to the 5th speed gear.



398

The 5th and reverse speed synchronizer rings are smaller than the other synchronizer rings in this transmission.

The 5th speed synchronizer ring has not the special EFM II coating. The reverse synchronizer ring has the special EFM II coating.




EA073

## Front Section Assembly


1. Place the front housing with input shaft and countershaft bearing cups side facing up.
2. Position the 4th speed synchronizer ring on the input shaft. Refer to "Synchroizer Assemblies", in this manual.




3. Install the input shaft with the positioned synchronizer ring onto the mainshaft front bearing cone. The synchronizer ring lugs must slide into the synchronizer hub key slots.



4. With the input shaft down, position the input shaft and mainshaft assembly on the front housing.




5. Position the 3rd/4th speed shift yoke and bar and the countershaft on the mainshaft assembly, holding the whole assembly with the hands.




6. Align the whole assembly, as set before, with the input shaft bearing cup, with the countershaft bearing cup and with the 3rd/4th yoke bar bore, and install the assembly in the front housing.

**Note:** Be careful to keep the double shifting interlock balls in place.




7. Install the 1st/2nd shift yoke in the respective synchronizer sleeve groove.



615


8. Install the 1st/2nd yoke bar in its respective bar bore. The bar notch must be at the lower side.

**Note:** Be careful to keep the double shifting interlock balls in place.



615

9. Align the shift yoke with the yoke bar matching the roll pin holes and install the retaining roll pin using a 4 mm diameter pin punch. The 1st/2nd yoke bar notch should be aligned with the 3rd/4th shift block groove, formerly installed.



615


10. Install the shift selector bar in the bar bore, positioning the shortest arm of the selector block between the 1st/2nd yoke bar notch and the 3rd/4th shift block groove. The longest arm must be ahead the reverse shifting interlocking mechanism. To do that, rotate the interlocking mechanism by hand while positioning the shift selector bar.

**Note:** Be careful to keep the double shifting interlock balls in place.



607

11. Align the 5th/reverse yoke bar with its respective bar bore, with the longest arm of the selector block and with the reverse shifting interlock pin, and install the yoke bar.



626

**WARNING!** Do not apply sealant to both housing and retaining capscrews by now! Prior to finishing the transmission assembly is necessary to check the end play.

12. Install the intermediate housing on the front housing.


**Note:** If necessary, carefully hit the housing's capscrews area with a plastic hammer to match the housings.



157

13. Install the intermediate housing retaining capscrews. Tighten capscrews crosswise to the recommended torque.


**Note:** Torque = 19-25 N.m (14-19 Lb.ft)



652

14. From inside the front housing, install capscrews securing the front housing to the intermediate housing. Tighten capscrews to the recommended torque.

Torque = 19-25 N.m (14-19 Lb.ft)




003

15. Proceed to mainshaft and countershaft end play adjustment as recommended in "End Play Adjustment", later in this manual.

16. After determining the shim pack thickness necessary for adjusting both mainshaft and countershaft end play, remove intermediate housing.

17. Use the proper drive tool and remove the rear bearing cups (see "Mainshaft and Countershaft Rear Bearing Cups – Removal and Installation").

**WARNING!** Be careful not to swap the adjustment shim packs between mainshaft and countershaft when installing them.




EA173

18. Install the necessary shim pack thickness to adjust the mainshaft end play in the mainshaft rear bearing bore and next, install the bearing cup.

**Note:** Use the proper drive tool to install the bearing cup (see "Mainshaft and Countershaft Rear Bearing Cups – Removal and Installation").


19. Install the necessary shim pack thickness to adjust the countershaft end play in the countershaft rear bearing bore and next, install the bearing cup.

**Note:** Use the proper drive tool E024001 to install the bearing cup (see “Mainshaft and Countershaft Rear Bearing Cups – Removal and Installation”).




EA174

20. Remove any remaining sealant material from housing mounting surfaces.




888

21. Use either a proper tap or screw and remove any remaining sealant material from housing threaded holes.



896


22. Apply a Eaton 680 sealant string of approximately 1.5 mm (1/16 inch) of thickness to the center of the front housing mounting surface.



FSO-2105/3a

23. Install the intermediate housing on the front housing.


**Note:** If necessary, carefully hit the housing's capscrews area with a plastic hammer to match the housings.



157

24. Apply Eaton 677 sealant to threads of the thirteen retaining capscrews that secure the intermediate housing to the front housing and install the capscrews, tightening by hand until capscrews are snug. Next, tighten capscrews crosswise to the proper torque.

Torque = 19-25 N.m (14-19 Lb.ft)



EA126

25. From inside the front housing, install capscrews securing the front housing to the intermediate housing. Tighten capscrews to the proper torque.

**Note:** Apply Eaton 677 sealant to capscrew threads.

Torque = 19-25 N.m (14-19 Lb.ft)



26. Remove the shift positioning plug, spring and ball, using the special tool E018001.



27. Assemble the rear section (refer to Rear Section Assembly", in this manual).

## End Play Adjustment

**WARNING!** Before measuring and adjusting the transmission axial clearance (end play), remove ALL existing adjusting shims under both the mainshaft and countershaft rear bearing cups (refer to "Mainshaft and Countershaft Rear Bearing Cups - Removal and Installation", in this manual).

The bearing cups must have been installed in the bearing bores completely clean and perfectly seated on the bearing bore bottom.

**Note:** Special tools used for measuring the end play: see "Tool Information", Ref. E008001 and E009005.

## Mainshaft End Play Measurement

1. Choose one from housing threaded holes and install the special plate (E009005) to support a dial indicator gauge with magnetic base.



2. Install the mainshaft rear nut just a few threads to support the pry bar (tool # E008001).



3. Rotate the mainshaft several times in both directions clockwise and counterclockwise to make sure the mainshaft is completely seated on the bearing.
4. Set the dial indicator tip against the mainshaft end. Set the pointer to zero.



5. Place the pry bar (tool # E008001) under the mainshaft nut and push the mainshaft upwards at once. Keep the mainshaft in that position while taking the dial indicator reading. Record that reading.




### Countershaft End Play Measurement

1. Choose one from housing threaded holes and install the special plate (E009005) to support a dial indicator with magnetic base.
2. Install one from those removed transmission capscrews in the hole at countershaft end center. The capscrew head will be used as a base to set the dial indicator tip.
3. Rig up some kind of support on the countershaft to support the pry bar (tool # E008001).
4. Rotate the countershaft several times in both directions clockwise and counterclockwise to make sure the countershaft is completely seated on the bearing.
5. Set the dial indicator tip against the capscrew head threaded in the countershaft end center. Set the pointer to zero.
6. Place the pry bar (tool # E008001) under the countershaft rigged-up support and push the countershaft upwards at once. Keep the countershaft in that position while taking the dial indicator reading. Record that reading.

### Determining Shim Pack Thickness for End Play Adjustment

|                      | Specified end play (mm) |         |                    |
|----------------------|-------------------------|---------|--------------------|
|                      | Minimum                 | Maximum | Remarks            |
| <b>Counter-shaft</b> | 0.06                    | 0.11    | Positive clearance |
| <b>Mainshaft</b>     | 0.06                    | 0.11    | Positive clearance |

Use the following flowchart and determine the shim pack thickness to adjust the transmission end play:



#### Example #1: countershaft end play adjustment

Specified end play: 0.06 mm to 0.11 mm  
Measured end play: 0.47 mm

As the measured value is greater than 0.11 mm (maximum specified), calculate:

$$0.47 - 0.11 = 0.36 \text{ mm (R1)}$$

$$0.47 - 0.06 = 0.41 \text{ mm (R2)}$$

The shim pack thickness must be within 0.36 mm and 0.41 mm.

#### Example #2: countershaft end play adjustment

Specified end play: 0.06 mm to 0.11 mm  
Measured end play: 0.02 mm

In this case, it is not possible to calculate the shim thickness, since the measured clearance is already less than the minimum specified. This measured value is not a valid value. So, it is necessary to redo the measurement, verifying before if all existing shims were actually removed, if the bearing cup is perfectly seated on the bearing bore and free of any kind of dirt, and if the shaft is seated properly on the bearing, by rotating the shaft in both directions clockwise and counterclockwise.

Copyright Eaton Corporation 2009.  
Eaton hereby grants their customers,  
vendors, and distributors permission to freely  
copy, reproduce and/or distribute this  
document in printed format. It may be copied  
only in its entirety without any changes or  
modifications. THIS INFORMATION IS NOT  
INTENDED FOR SALE OR RESALE, AND  
THIS NOTICE MUST REMAIN ON ALL  
COPIES.

